

Intermittent Fault Box (model 2112)

Features:

The Intermittent Fault Box provides a means of faulting circuits in vehicles.

- Faulted circuits are connected through standard banana jacks. The following faults can be inserted:
 - » Open
 - » Incorrect Resistance
 - » Short to Ground
 - » Short to Voltage
- Fault duration switch.
- Time between fault switch.
- Hard and intermittent switch.



Call Now to Place your Order (Press 2 for Sales)

ATech Training, Inc.
Toll Free: 1-888-738-9924
Phone: 859-485-7229 • Fax: 859-485-7299
E-mail: sales@atechtraining.com
www.atechtraining.com

ATech
Automotive Technology